Assembly Instructions for: item 4060 & 4062 Tuxedo Series - Sconce & Double Sconce

Important: Always unplug the power cord before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

A WAY OF LIGHT

Assembly & Installation Instructions

SONNEMAN

- 1. Shut off power to outlet box.
- 2. Place Mounting Plate over outlet box and secure it with two screws.
- 3. Make appropriate electrical connections using wire nuts.
- Connect the black fixture wire to black supply wire. Connect

white fixture wire to white supply wire.

If there is no green ground wire from the outlet box,

connect the fixture ground wire to the mounting plate with

the green screw provided. Place connections in outlet box.

- 4. Place Backplate over Mounting Plate and secure it with back plate screws.
- 5. Insert bulb in socket (not included).
- 6. Place Glass Cylinder over bulb.
- 7. Restore power to fixture.

