VEM/ A WAY OF LIGHT

Assembly Instructions for item: 4610

А

E12 Candelabra base bulb

OFF

Important: Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.

This light should be installed by a licensed electrician



- 1. Shut off power to the outlet box. (fig. A)
- 2. Attach the mounting plate to the outlet box, secure with outlet box screws.
- 3. Make appropriate electrical connections using wire nuts:
 - a. Connect the fixture's live wire (black) to the live outlet box wire.
 - b. Connect the fixture's neutral wire (white) to the neutral outlet box wire.
 - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections in outlet box.
- 4. Install the back plate to the mounting plate by hooking the tab inside the back plate behind the bend on the mounting plate, then tipping the back plate against the wall (fig. B). Secure with mounting screws.
- 5. Attach the shade to the fixture by placing the covers over the socket cups.
- 6. Install 60W E12 Candelabra base bulbs. (not included)
- 7. Restore power to the fixture.

